



# Bouton bas flèche caps métal

# STÖCKLI




Fixation par pince

Ø	REFERENCE
3	311-23-39
4	311-23-49
5	311-23-59
6	311-23-69
1/8"	311-23-19
1/4"	311-23-29




Fixation par vis


Ø	REFERENCE
3	111-23-39
4	111-23-49
6	111-23-69
1/8"	111-23-19
1/4"	111-23-29




Ø	REFERENCE
3	311-24-39
4	311-24-49
5	311-24-59
6	311-24-69
1/8"	311-24-19
1/4"	311-24-29



Ø	REFERENCE
3	111-24-39
4	111-24-49
6	111-24-69
1/8"	111-24-19
1/4"	111-24-29





Ø	REFERENCE
3	311-25-39
4	311-25-49
5	311-25-59
6	311-25-69
1/8"	311-25-19
1/4"	311-25-29





Ø	REFERENCE
4	111-25-49
6	111-25-69
1/4"	111-25-29

A vis seulement



Ø	REFERENCE
4	111-26-49
6	111-26-69
8	111-26-89
10	111-26-09
1/4"	111-26-29



Ø	REFERENCE
4	111-27-49
6	111-27-69
8	111-27-89
10	111-27-09
1/4"	111-27-29