



Bouton Haut simple caps métal


STÖCKLI

Fixation par pince


Fixation par vis




Ø	REFERENCE
3	310-03-39
4	310-03-49
5	310-03-59
6	310-03-69
1/8"	310-03-19
1/4"	310-03-29





Ø	REFERENCE
3	110-03-39
4	110-03-49
6	110-03-69
1/8"	110-03-19
1/4"	110-03-29




Ø	REFERENCE
3	310-04-39
4	310-04-49
5	310-04-59
6	310-04-69
1/8"	310-04-19
1/4"	310-04-29




Ø	REFERENCE
3	110-04-39
4	110-04-49
6	110-04-69
1/8"	110-04-19
1/4"	110-04-29




Ø	REFERENCE
3	310-05-39
4	310-05-49
5	310-05-59
6	310-05-69
1/8"	310-05-19
1/4"	310-05-29



Ø	REFERENCE
4	110-05-49
6	110-05-69
1/4"	110-05-29





Ø	REFERENCE
4	310-06-49
5	310-06-59
6	310-06-69
1/4"	310-06-29



Ø	REFERENCE
4	110-06-49
6	110-06-69
8	110-06-89
10	110-06-09
1/4"	110-06-29

A vis seulement



Ø	REFERENCE
4	110-07-49
6	110-07-69
8	110-07-89
10	110-07-09
1/4"	110-07-29