



Bouton bas flèche standard

STÖCKLI




Fixation par pince

Ø	REFERENCE
3	301-23-30
4	301-23-40
5	301-23-50
6	301-23-60
1/8"	301-23-10
1/4"	301-23-20




Fixation par vis


Ø	REFERENCE
3	101-23-30
4	101-23-40
6	101-23-60
1/8"	101-23-10
1/4"	101-23-20




Ø	REFERENCE
3	301-24-30
4	301-24-40
5	301-24-50
6	301-24-60
1/8"	301-24-10
1/4"	301-24-20



Ø	REFERENCE
3	101-24-30
4	101-24-40
6	101-24-60
1/8"	101-24-10
1/4"	101-24-20






Ø	REFERENCE
3	301-25-30
4	301-25-40
5	301-25-50
6	301-25-60
1/8"	301-25-10
1/4"	301-25-20





Ø	REFERENCE
4	101-25-40
6	101-25-60
3/8"	101-25-90

A vis seulement



Ø	REFERENCE
4	101-26-40
6	101-26-60
8	101-26-80
10	101-26-00
1/4"	101-26-20
3/8"	101-26-90



Ø	REFERENCE
4	101-27-40
6	101-27-60
8	101-27-80
10	101-27-00
1/4"	101-27-20
3/8"	101-27-90

Pour un autre coloris de tête voir page 5.